

Part # 6845

R-1234yf Charging Hose

- Turn actuator valve handle clockwise until it stops to retract the inner stem.
- 2. Attach valve assembly and hose to the top of the R-1234yf refrigerant can (left hand thread).
- 3. Hold back the sliding ring of the quick coupler while pushing connector onto vehicle's A/C LOW SIDE service port.
- 4. Start the vehicle's engine. Turn A/C to MAX COOL and fan switch to high.
- 5. Turn actuator valve handle counterclockwise until it stops. Allow refrigerant to enter the vehicle's A/C system.
- 6. While charging, rotate can between 12 o'clock and 3 o'clock, continually agitating (sweeping) can back and forth. Continue until the can is empty, usually 5-7 minutes, or until the correct amount of charge is reached. DO NOT OVERCHARGE THE SYSTEM.
- 7. When the correct amount of charge is reached, turn actuator handle clockwise until it stops.
- 8. Pull sliding ring up on the quick coupler and remove it from port.
- 9. If the R-1234yf can is empty, remove it from the charging hose and discard. Save and reuse the charging hose for future use.

CAUTION: Always wear hand and eye protection when servicing a vehicle's A/C system