

Part # 6040

R-134a/R-12 Side Can Tap

Instructions



- (1) For refrigerant charging, remove the oil charge adapter from the can tap.
- (2) Unlatch the can tap handles from each other and spread apart.
- (3) Slide the can tap over the top of the can of refrigerant and bring the two handles towards one another until the latches at the bottom of each handle lock together.
- (4) Attach a charging hose to the can tap.
- (5) Charge the R-134a/R-12 A/C system per OEM specifications

WARNING: ALWAYS WEAR SAFETY GOGGLES WHEN USING THIS PRODUCT

FJC Air Conditioning Products—Tools, Equipment & Refrigerant